



Installation manual

Daikin room air conditioners



ATXF20C5V1B
ATXF25C5V1B
ATXF35C5V1B
ATXF42C5V1B

Installation manual
Daikin room air conditioners

English

CE - DECLARATION-OF-CONFORMITY	CE - DECLARACION-DE-CONFORMIDAD
CE - KONFORMITÄTSERKLÄRUNG	CE - DICHIARAZIONE-DI-CONFORMITÀ
CE - DECLARATION OF CONFORMITE	CE - ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ
CE - KONFORMITÄTSSVERKLÄRUNG	

CE - DECLARAÇÃO-DE-CONFORMIDADE
CE - ЗАЯВЛЕНИЕ-О-СООТВЕТСТВИИ
CE - ÖVERENSSTÄMMELSEERKLÄRING
CE - FÖRSÄKRAN-OM-ÖVERENSSTÄMMELSE

CE - ERKLÆRING OM-SAMSVAR
CE - ILMOITUS-YHDENMUKAISUUDESTA
CE - PROHLÁŠENÍ-O-SHOĐĚ

CE - IZJAVA-O-USKLAĐENOSTI
CE - MEGFELELŐSÉGI-NYILATKOZAT
CE - DEKLARACIJA-ZGODNOSTI
CE - DECLARATION-DE-CONFORMITE

CE - IZJAVA O SKLADNOSTI
CE - VASTAVUSDEKLARATSIOON
CE - ДЕКЛАРАЦИЯ-ЗА СЪОТВЕТСТВИЕ

CE - ATITIKTIES-DEKLARĀCIJA
CE - ATBILSTĪBAS-DEKLARĀCIJA
CE - VYHLÁŠENIE-ZHODY
CE - UYGUNLŪK-BEYANI

Daikin Europe N.V.

0102 decares under its sole responsibility that the equipment to which this declaration relates:
0103 erklart at sine ansvarlige Verantworsung dat de Ausrüstung für dieses Erklärungsbestimm ist
0104 déclare sous sa seule responsabilité que l'équipement visé par la présente déclaration
0105 verklaart hierbij op zijn exclusieve verantwoordelijkheid dat de ausrusting waarop deze verklaring
0106 betreft, onder zijn uitsluitende aansprakelijkheid staat.
0107 dichiara sotto la propria responsabilità che gli apparecchi a cui si riferita questa dichiarazione:
0108 bylägges till ensammanstans ansvar för utrustningen som omfattas av denna förklaring.
0109 decares sous sa seule responsabilité que l'équipement auquel se réfère cette déclaration
0110 erklærer under sin ene ansvarsholdelse, at udstyret, som er omfattet af denne erklæring, er

[illegible]

FTXF20C5V1B, FTXF25C5V1B, FTXF35C5V1B, FTXF42C5V1B,
ATXF20C5V1B, ATXF25C5V1B, ATXF35C5V1B, ATXF42C5V1B,
CTXF20C5V1B, CTXF25C5V1B, CTXF35C5V1B,

[illegible]

05 están en conformidad con la(s) siguiente(s) norma(s) u otro(s) documento(s) normativo(s), siempre que sean utilizados de acuerdo con nuestras instrucciones:

306 sono conformi all(i) seguente(i) standard(s) o all(tri) documento(i) a carattere normativo, a patto che vengano usati in conformità alle nostre istruzioni
307 είναι σύμφωνα με τ(α) ακόλουθ(α) πρότυπο(α) ή άλλο(α) έγγραφο(α) κανονισμ(α)ίων, υπό την προϋπόθεσις ότι χρησιμοποιούνται σύμφωνα με τις οδηγίες μας:

EN60335-2-40,

01	following the provisions of:	01	nakoljedno na temelju odredbi:
02	gemäß den Vorschriften der:	02	konkretno na temelju odredbi:
03	concerning the situations des:	03	konkretno u situacijama des:
04	overeenkomstig de bepalingen van:	04	u skladu s odredbama:
05	siguendo las disposiciones de:	05	u skladu s odredbama:
06	secondo le prescrizioni per:	06	prema odredbama:
07	je tñrñu ju bñrññu tñv:	07	prema odredbama:
08	de acordo com o previso et:	08	prema odredbama:
09	in соответствии с положениями:	09	prema odredbama:
10	under the provisions of:	10	prema odredbama:
11	enligt föreskrifterna i:	11	prema odredbama:
12	gitl'henhold til bestemmelserne i:	12	prema odredbama:
13	noudatnen mairay'sa:	13	prema odredbama:
14	za dodrñen ustanovñ predpisu:	14	prema odredbama:
15	prema odredbama:	15	prema odredbama:
16	koviñ alzi:	16	prema odredbama:
17	zgodno z postavitvenimi Direktiv:	17	prema odredbama:
18	in urma prevederilor:	18	prema odredbama:

01 Not*	as set out in <A> and judged positively by according to the <i>Uitdaging</i> <C>	06 Not*	delineato nel <A> e giudicato positivamente da secondo il <i>Certificato</i> <C>
02 Hinweis*	was in <A> aufgeführt und von positiv beurteilt gemäss <i>Zertifikat</i> <C>	07 Zetjeloont*	amto in <A> kátoirto oio <A> xar kátoirto Bérnd <C> amto in oiojunga mi to <i>Platomonito</i> <C>
03 Remarque*	lequel que défini dans <A> et évalué positivement par 08 Not*	08 Not*	tal como estabelecido em <A> e como o parecer po de de acordo com o <i>Certificado</i> <C>
04 Bemerk*	zoals vermeld in <A> en positief beoordeeld door 09 Pmwewas*	09 Pmwewas*	na uytzakeho in <A> na omettersen ts monokomparat peusemen o conatoio <i>Capmewas</i> <C>
05 Nota*	positivamente por 10 Bemerk*	10 Bemerk*	posiivnente por 11 Hien Certifikat <C>

01** Dalkin Europeo N.V. is authorised to compile the Technical Construction File.
02** Dalkin Europeo N.V. hat die Berechtigung die Technische Konstruktionsakte zusammenzustellen.
03** Dalkin Europeo N.V. est autorisé à compiler le Dossier de Construction Technique.
04** Dalkin Europeo N.V. is bevoegd om het Technisch Constructiedossier samen te stellen.
05** Dalkin Europeo N.V. está autorizado a compilar el Archivo de Construcción Técnica.
06** Dalkin Europeo N.V. è autorizzato ad a redigere il File tecnico di Costruzione.

07	H Dalkin Europe N.V. είναι εξουσιοδοτημένη να συντάξει τον Τεχνικό φάκελο κατασκευής.
08	A Dalkin Europe N.V. está autorizada a compilar a documentação técnica de fabrico.
09	Компания Дайкин Еуропа N.V. уполномочена составлять Технический документ
10	Dalkin Europe N.V. er autoriseret til at udarbejde de tekniske konstruktionsdata.
11	Dalkin Europe N.V. er bemyndigede til samstemsåttle den tekniske konstruktionsfilen.
12	Dalkin Europe N.V. har tilatelse til å compilere den Tekniske konstruksjonsfilen.

- 13^o Daikin Europe N.V. on valtuutettu laatimaan Teknisen asiansiirajan.
- 14^o Společnost Daikin Europe N.V. má oprávnění ke kompilaci souborů.
- 15^o Daikin Europe N.V. je ověřen za izradu Datoteke o tehničkih kolonah.
- 16^o A Daikin Europe N.V. jogsullta a mlszaki konstrukciós dokumentációt.
- 17^o Daikin Europe N.V. má upoważnienie do zbierania i opracowywania danych.
- 18^o Daikin Europe N.V. este autorizat să compileze Documentul tehnic de

08 estão em conformidade com a(s) seguinte(s) norma(s) ou outro(s) documento(s) normativo(s), desde que estes sejam utilizados de acordo com as nossas instruções:

09. соответствующим стандартам или другим нормативным документам, при условии их использования согласно нашим инструкциям;
10. overholder følgende standard(er) eller andre relevante retningsvise dokument(er), forudsat at disse anvendes i henhold til vores instruktioner.

11 respektive utrustning af udført i overensstemmelse med og følger følgende standard(er) eller andre normgivende dokument, under forudsætning af anvendelse i overensstemmelse med de instruktioner.

12 respektive udstyr af i overensstemmelse med følgende standard(er) eller andre normgivende dokument(er), under forudsætning af at disse bruges i henhold til de instruktioner.

13 vastaavat seuraavien standardien ja muiden ohjeellisten dokumenttien vaatimuksia edellyttäen, että niitä käytetään ohjeidenme mukaisesti:
14 za předpokladu, že jsou využívány v souladu s našimi pokyny, obvodími následujícími normami nebo normativními dokumenty:

15 u skladu sa slijedećim standardom(ima) ili drugim normativnim dokumentom(ima), uz uvjet da se oni koriste u skladu s našim uputama:

Low Voltage 2014/35/EU
Electromagnetic Compatibility 2014/30/EU
Machinery 2006/42/EC

11 Information*	enigi <A> od gorkilans ar enligi Certificati <A>	16 Meugjyzyse
12 Merk*	son del ferikormer <A> qg gernom positiv bedemelse ar folge Seriffikat	17 Uwaga*
13 Huom*	poka on eselity asselasy <A> pila on tyvyslyny Seriffikat <A> mukallesi	18 Nola*
14 Poznamka*	kak bio uvideno v <A> pozitivne zjsteno v sroudu s osvjetlenim 	19 Opomba*
15 Napomena*	kako je izobezeno v <A> pozitivno ocjeleno od strane prema Certificatu 	20 Markus*

13**	Dakin	ολοκληρωμένη να συντάξει τον Τεχνικό φάκελο κατασκευής,
14**	Spoleto	αποδοχή να συμπληρώσει το έγγραφο κατασκευής.
15**	Dakin	αποδοχή να συμπληρώσει το έγγραφο κατασκευής.
16**	A. Dakin	αποδοχή να συσταθεί η τεχνική ομάδα κατασκευής.
17**	Dakin	αποδοχή να συσταθεί η τεχνική ομάδα κατασκευής.
18**	Dakin	αποδοχή να συσταθεί η τεχνική ομάδα κατασκευής.

21 Zábodnopol	22 Pastaba*	24 Poznámla*	25 Not*
23 Zábodnopol	23 Poznámla*		

rope N.V. on valitud ühtlasi Teknisen asakijana. Dainik Europe N.V. mä õpravnõni ke komplici souboru tehnikõke konsultant. Europe N.V. ke õvõsten za trazu Datexeko d tehnikõj konsultõj. Europe N.V. jogsõult a mõzaki konstruktsõk dokumentatsõi õsseealitsasõi. Europe N.V. ma upõvõznõie dõ zbierania i oprowõwniania dokumentacõj i karteõi. Europe N.V. este autorizõr sã complice Dosnall tehnic de conõuctie.

megfelelnek az alábbi szabvány(ok)nak vagy egyéb irányadó dokumentum(ok)nak, ha azokat előírás szerint használják:
szempontja a megadott normák és szabványok követelményeinek megfelelően.
A megadott normák és szabványok követelményeinek megfelelően.

19 skladni z naslednjimi standardi in drugimi normativi, pod pogojem, da se uporabljajo v skladu z našimi navodili:
20 on postavitev Jarqin's (le standard) (le v oči teiste normativne dokumentacije, ki ne deli kasualneke postavali meje in nedelje;

221 съответстват на следните стандарти или други нормативни документи, при условие, че се използват съгласно нашите инструкции:
222 altlinka žemial nurodovius standartas / t arba kitus norminius dokumentus su sąlyga, kad yra naudojami pagal mūsų nurodymus;

23 Iad, ja tebi atibšiši rāzājā norāžijumem, atibšis ekošiem standāriem un citiem normatīviem dokumentiem:
24 si v zibos s nasedovnu(n) normou(ām) alebo n(n)mi(n) normatīvi(n)mi dokumentu(ām), za predpoku, že sa poži(v)u silade s našim

návodom:

25. Ürünün, talimatlarımıza göre kullanılması koşuluyla aşağıdaki standartlar ve norm belirten belgelerle uyumludur;

[illegible]

<A>	DAIKIN.TCF.032E7/11-2020
	DEKRA (NB0344)
<C>	2159619.0551-EMC

- 19th Dákin Europe N.V. je pobližen za sestavo datoteke z temničo mapo.
- 20th Dákin Europe N.V. on volatidu kostonna teminis dokumentatsion.
- 21th Dákin Europe N.V. je omprigajana za čuvstvo Arta za revnikova okupacija.
- 22th Dákin Europe N.V. je prajata sudajni šitchninis konstruktsijas fajla.
- 23th Dákin Europe N.V. je audritelsi sestadi temishno dokumentatsiji.
- 24th Spojnost Dákin Europe N.V. je opravjena vivotni sudov tehnolohije konstrukcije.

3P516375-15Q

DAIKIN

Hiromitsu Iwasaki
Director

Ostend, 4th of January 2021

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

Table of contents

1	About the documentation	3
1.1	About this document.....	3
2	Specific installer safety instructions	3
3	About the box	5
3.1	Indoor unit	5
3.1.1	To remove the accessories from the indoor unit.....	5
4	About the unit	5
4.1	System layout.....	5
4.2	Operation range	5
5	Unit installation	6
5.1	Preparing the installation site	6
5.1.1	Installation site requirements of the indoor unit	6
5.1.2	Additional installation site requirements of the outdoor unit in cold climates	6
5.2	Opening the indoor unit	6
5.2.1	To remove the front panel.....	6
5.2.2	To re-install the front panel	6
5.2.3	To remove the front grille	6
5.2.4	To re-install the front grille	7
5.2.5	To remove the electrical wiring box cover.....	7
5.2.6	To open the service cover.....	7
5.3	Mounting the indoor unit.....	7
5.3.1	To install the mounting plate	7
5.3.2	To drill a wall hole	7
5.3.3	To remove the pipe port cover	8
5.3.4	To provide drainage	8
6	Piping installation	9
6.1	Preparing refrigerant piping	9
6.1.1	Refrigerant piping requirements.....	9
6.1.2	Refrigerant piping insulation	9
6.2	Connecting the refrigerant piping	9
6.2.1	Guidelines when connecting the refrigerant piping	9
6.2.2	To connect the refrigerant piping to the indoor unit	10
6.3	Checking the refrigerant piping	10
6.3.1	To check for leaks	10
6.3.2	To perform vacuum drying	10
7	Electrical installation	10
7.1	Specifications of standard wiring components	11
7.2	To connect the electrical wiring to the indoor unit	11
8	Finishing the indoor unit installation	11
8.1	To insulate the drain piping, refrigerant piping and interconnection cable	11
8.2	To pass the pipes through the wall hole.....	11
8.3	To fix the unit on the mounting plate	12
9	Configuration	12
9.1	To set a different address.....	12
10	Commissioning	13
10.1	Checklist before commissioning	13
10.2	To perform a test run.....	13
10.2.1	To perform a test run in winter season	13
11	Disposal	13
12	Technical data	14
12.1	Wiring diagram	14
12.1.1	Unified wiring diagram legend.....	14

1 About the documentation

1.1 About this document

Target audience



INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry, and on farms, or for commercial and household use by lay persons.



WARNING

Make sure installation, servicing, maintenance, repair and applied materials follow the instructions from Daikin and, in addition, comply with applicable legislation and are performed by qualified persons only. In Europe and areas where IEC standards apply, EN/IEC 60335-2-40 is the applicable standard.



INFORMATION

This document only describes installation instructions specific to the outdoor unit. For installation of the indoor unit (mounting the indoor unit, connecting the refrigerant piping to the indoor unit, connecting the electrical wiring to the indoor unit ...), see the installation manual of the indoor unit.

Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
 - Safety instructions that you **MUST** read before installing
 - Format: Paper (in the box of the indoor unit)
- **Indoor unit installation manual:**
 - Installation instructions
 - Format: Paper (in the box of the indoor unit)
- **Installer reference guide:**
 - Preparation of the installation, good practices, reference data,...
 - Format: Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

The original documentation is written in English. All other languages are translations.

2 Specific installer safety instructions

Always observe the following safety instructions and regulations.

Unit installation (see "**5 Unit installation**" ► 6))



WARNING

Installation shall be done by an installer, the choice of materials and installation shall comply with the applicable legislation. In Europe, EN378 is the applicable standard.

2 Specific installer safety instructions

Installation site (see ["5.1 Preparing the installation site"](#) ▶ 6))



CAUTION

- Check if the installation location can support the unit's weight. Poor installation is hazardous. It can also cause vibrations or unusual operating noise.
- Provide sufficient service space.
- Do NOT install the unit so that it is in contact with a ceiling or a wall, as this may cause vibrations.

Connecting the refrigerant piping (see ["6.2 Connecting the refrigerant piping"](#) ▶ 9))



CAUTION

- No brazing or welding on site for units with R32 refrigerant charge during shipment.
- During installation of the refrigeration system, joining of parts with at least one part charged shall be performed taking into account the following requirements: inside occupied spaces non permanent joints are not allowed for R32 refrigerant except for site made joints directly connecting the indoor unit to piping. Site made joints directly connecting piping to indoor units shall be of non permanent type.



CAUTION

- Use the flare nut fixed to the unit.
- To prevent gas leakage, apply refrigeration oil only to the inside of the flare. Use refrigeration oil for R32.
- Do NOT reuse joints.



CAUTION

- Do NOT use mineral oil on flared part.
- Do NOT reuse piping from previous installations.
- NEVER install a drier to this R32 unit to guarantee its lifetime. The drying material may dissolve and damage the system.



WARNING

Connect the refrigerant piping securely before running the compressor. If the refrigerant piping is NOT connected and the stop valve is open when the compressor is run, air will be sucked in. This will cause abnormal pressure in the refrigeration cycle, which may result in equipment damage and even injury.



CAUTION

- Incomplete flaring may cause refrigerant gas leakage.
- Do NOT re-use flares. Use new flares to prevent refrigerant gas leakage.
- Use flare nuts that are included with the unit. Using different flare nuts may cause refrigerant gas leakage.



CAUTION

Do NOT open the valves before flaring is complete. This would cause refrigerant gas leakage.



DANGER: RISK OF EXPLOSION

Do NOT start the unit if it is vacuumed.

Charging refrigerant (see [Charging refrigerant](#))



WARNING

The refrigerant inside the unit is mildly flammable, but normally does NOT leak. If the refrigerant leaks in the room and comes in contact with fire from a burner, a heater, or a cooker, this may result in fire, or the formation of a harmful gas.

Turn off any combustible heating devices, ventilate the room, and contact the dealer where you purchased the unit.

Do NOT use the unit until a service person confirms that the part from which the refrigerant leaked has been repaired.



WARNING

- Only use R32 as refrigerant. Other substances may cause explosions and accidents.
- R32 contains fluorinated greenhouse gases. Its global warming potential (GWP) value is 675. Do NOT vent these gases into the atmosphere.
- When charging refrigerant, ALWAYS use protective gloves and safety glasses.



CAUTION

To avoid compressor breakdown, do NOT charge more than the specified amount of refrigerant.



WARNING

NEVER directly touch any accidental leaking refrigerant. This could result in severe wounds caused by frostbite.

Electrical installation (see ["7 Electrical installation"](#) ▶ 10))



WARNING

Appliance shall be installed in accordance with national wiring regulations.



WARNING

- All wiring MUST be performed by an authorised electrician and MUST comply with the applicable legislation.
- Make electrical connections to the fixed wiring.
- All components procured on-site and all electrical construction MUST comply with the applicable legislation.



WARNING

- If the power supply has a missing or wrong N-phase, equipment might break down.
- Establish proper earthing. Do NOT earth the unit to a utility pipe, surge absorber, or telephone earth. Incomplete earthing may cause electrical shock.
- Install the required fuses or circuit breakers.
- Secure the electrical wiring with cable ties so that the cables do NOT come in contact with sharp edges or piping, particularly on the high-pressure side.
- Do NOT use taped wires, stranded conductor wires, extension cords, or connections from a star system. They can cause overheating, electrical shock or fire.
- Do NOT install a phase advancing capacitor, because this unit is equipped with an inverter. A phase advancing capacitor will reduce performance and may cause accidents.

**WARNING**

ALWAYS use multicore cable for power supply cables.

**WARNING**

Use an all-pole disconnection type breaker with at least 3 mm between the contact point gaps that provide full disconnection under overvoltage category III.

**WARNING**

If the supply cord is damaged, it MUST be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

**WARNING**

Do NOT connect the power supply to the indoor unit. This could result in electrical shock or fire.

**WARNING**

- Do NOT use locally purchased electrical parts inside the product.
- Do NOT branch the power supply for the drain pump, etc. from the terminal block. This could result in electrical shock or fire.

**WARNING**

Keep the interconnection wiring away from copper pipes without thermal insulation as such pipes will be very hot.

**DANGER: RISK OF ELECTROCUTION**

All electrical parts (including thermistors) are powered by the power supply. Do not touch them with bare hands.

**DANGER: RISK OF ELECTROCUTION**

Disconnect the power supply for more than 10 minutes, and measure the voltage at the terminals of main circuit capacitors or electrical components before servicing. The voltage MUST be less than 50 V DC before you can touch electrical components. For the location of the terminals, see the wiring diagram.

Finishing indoor unit installation (see [Finishing the outdoor unit installation](#))

**DANGER: RISK OF ELECTROCUTION**

- Make sure that the system is earthed properly.
- Turn off the power supply before servicing.
- Install the switch box cover before turning on the power supply.

Commissioning (see ["10 Commissioning"](#) ▶ 13)]

**DANGER: RISK OF ELECTROCUTION****DANGER: RISK OF BURNING/SCALDING****CAUTION**

Do NOT perform the test operation while working on the indoor units.


When performing the test operation, NOT only the outdoor unit, but the connected indoor unit will operate as well. Working on an indoor unit while performing a test operation is dangerous.

**CAUTION**

Do NOT insert fingers, rods or other objects into the air inlet or outlet. Do NOT remove the fan guard. When the fan is rotating at high speed, it will cause injury.

3**About the box****3.1****Indoor unit****INFORMATION**


The following figures are just examples and may NOT completely match your system layout.

3.1.1**To remove the accessories from the indoor unit**

- a Installation manual
- b Operation manual
- c General safety precautions
- d Indoor unit fixing screw (M4×12L). Refer to ["8.3 To fix the unit on the mounting plate"](#) ▶ 12].
- e Dry battery AAA.LR03 (alkaline) for user interface
- f User interface holder
- g User interface
- h Mounting plate

4**About the unit****WARNING: MILDLY FLAMMABLE MATERIAL**

The refrigerant inside this unit is mildly flammable.

4.1**System layout**

- a Front cover
- b Service cover
- c Caulk pipe hole gap with putty
- d Refrigerant piping, drain hose and interconnection cable
- e Intelligent eye sensor
- f Insulation tape
- g Air filters

4.2**Operation range**

Operation mode	Operation range
Cooling ^{(a)(b)}	- Outdoor temperature: -10~46°C DB - Indoor temperature: 18~32°C DB - Indoor humidity: ≤80%
Heating ^(a)	- Outdoor temperature: -15~24°C DB - Indoor temperature: 10~30°C DB
Drying ^(a)	- Outdoor temperature: -10~46°C DB - Indoor temperature: 18~32°C DB - Indoor humidity: ≤80%

5 Unit installation

- ^(a) A safety device might stop the operation of the system if the unit runs outside its operation range.
- ^(b) Condensation and water dripping might occur if the unit runs outside its operation range.

5 Unit installation

5.1 Preparing the installation site



WARNING

Make sure installation, servicing, maintenance and repair comply with instructions from Daikin and with applicable legislation (for example national gas regulation) and are executed only by authorised persons.



WARNING

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).


5.1.1 Installation site requirements of the indoor unit



INFORMATION

The sound pressure level is less than 70 dBA.

- **Air flow.** Make sure nothing blocks the air flow.
- **Drainage.** Make sure condensation water can be evacuated properly.
- **Wall insulation.** When conditions in the wall exceed 30°C and a relative humidity of 80%, or when fresh air is inducted into the wall, then additional insulation is required (minimum 10 mm thickness, polyethylene foam).
- **Wall strength.** Check whether the wall or the floor is strong enough to support the weight of the unit. If there is a risk, reinforce the wall or the floor before installing the unit.
- **Spacing.** Install the unit at least 1.8 m from the floor and keep the following requirements in mind for distances from the walls and the ceiling:



5.1.2 Additional installation site requirements of the outdoor unit in cold climates


Protect the outdoor unit against direct snowfall and take care that the outdoor unit is NEVER snowed up.

In heavy snowfall areas it is very important to select an installation site where the snow will NOT affect the unit. If lateral snowfall is possible, make sure that the heat exchanger coil is NOT affected by the snow. If necessary, install a snow cover or shed and a pedestal.

5.2 Opening the indoor unit

5.2.1 To remove the front panel

- 1 Hold the front panel by the panel tabs on both sides and open it.




a Panel tabs

- 2 Remove the front panel by sliding it to the left or the right and pulling it toward you.

Result: The front panel shaft on 1 side will be disconnected.

- 3 Disconnect the front panel shaft on the other side in the same manner.



a Front panel shaft

5.2.2 To re-install the front panel

- 1 Attach the front panel. Align the shafts with the slots and push them all the way in.
- 2 Close the front panel slowly; press at both sides and at the centre.


5.2.3 To remove the front grille



CAUTION


Wear adequate personal protective equipment (protective gloves, safety glasses,...) when installing, maintaining or servicing the system.

- 1 Remove the front panel to remove the air filter.
- 2 Remove 2 screws from the front grille.
- 3 Push down the 3 upper hooks marked with a symbol with 3 circles.



a Upper hook
b Symbol with 3 circles

- 4 We recommend opening the flap before removing the front grille.
- 5 Place both hands under the centre of the front grille, push it up and then toward you.




5.2.4 To re-install the front grille

- 1 Install the front grille and firmly engage the 3 upper hooks.
- 2 Install 2 screws (class 20~42) back on the front grille.
- 3 Install the air filter and then mount the front panel.

5.2.5 To remove the electrical wiring box cover

- 1 Remove the front grille.
- 2 Remove 1 screw from the electrical wiring box.
- 3 Open the electrical wiring box cover by pulling the protruding part on the top of the cover.
- 4 Unhook the tab on the bottom and remove the electrical wiring box cover.




- a Tab
b Protruding part on the top of the cover
c Screw

- 5 To re-install the cover, first hook the bottom tab onto the electrical wiring box, and slide the cover into the 2 upper tabs.

5.2.6 To open the service cover

- 1 Remove 1 screw from the service cover.
- 2 Pull out the service cover horizontally away from the unit.



- a Service cover screw
b Service cover

5.3 Mounting the indoor unit


5.3.1 To install the mounting plate

- 1 Install the mounting plate temporarily.
- 2 Level the mounting plate.
- 3 Mark the centres of the drilling points on the wall using a tape measure. Position the end of tape measure at symbol ">".
- 4 Finish the installation by securing the mounting plate on the wall using M4×25L screws (field supply).



INFORMATION

The removed pipe port cover can be kept in the mounting plate pocket.



- A Mounting plate for class 20~42
a Recommended mounting plate fixing spots
b Pocket for the pipe port cover
c Tabs for placing a spirit level
d Through-the-wall hole Ø65 mm
e Drain hose position
f Position for the tape measure at symbol ">"
g Gas pipe end
h Liquid pipe end

5.3.2 To drill a wall hole



CAUTION


For walls containing a metal frame or a metal board, use a wall embedded pipe and wall cover in the feed-through hole to prevent possible heat, electrical shock, or fire.



NOTICE

Be sure to seal the gaps around the pipes with sealing material (field supply), in order to prevent water leakage.

- 1 Bore a 65 mm large feed-through hole in the wall with a downward slope towards the outside.
- 2 Insert a wall embedded pipe into the hole.
- 3 Insert a wall cover into the wall pipe.



- a Wall embedded pipe
b Putty
c Wall hole cover

- 4 After completing wiring, refrigerant piping and drain piping, do NOT forget to seal the gap with putty.


5 Unit installation

5.3.3 To remove the pipe port cover


i INFORMATION

To connect the piping on right-side, right-bottom, left-side or left-bottom, the pipe port cover **MUST** be removed.

- 1 Cut off the pipe port cover from inside the front grille using a coping saw.



- 2 Remove any burrs along the cut section using a half round needle file.



! NOTICE

Do **NOT** use nippers to remove the pipe port cover, as this would damage the front grille.


5.3.4 To provide drainage

Make sure condensation water can be evacuated properly. This involves:

- General guidelines
- Connecting the drain piping to the indoor unit
- Checking for water leaks


General guidelines

- **Pipe length.** Keep drain piping as short as possible.
- **Pipe size.** If drain hose extension or embedded drain piping is required, use appropriate parts that match the hose front end.




! NOTICE

- Install the drain hose with a downward slope.
- Traps are **NOT** permitted.
- Do **NOT** put the end of the hose in water.




- **Drain hose extension.** To extend the drain hose, use a field supplied hose with inner Ø16 mm. Do **NOT** forget to use a heat insulation tube on the indoor section of the extension hose.



- a Drain hose supplied with the indoor unit
- b Heat insulation tube (field supply)
- c Extension drain hose


- **Rigid polyvinyl chloride pipe.** When connecting a rigid polyvinyl chloride pipe (nominal Ø13 mm) directly to the drain hose as with embedded piping work, use a field supplied drain socket (nominal Ø13 mm).



- a Drain hose supplied with the indoor unit
- b Drain socket with nominal Ø13 mm (field supply)
- c Rigid polyvinyl chloride pipe (field supply)

- **Condensation.** Take measures against condensation. Insulate the complete drain piping in the building.

- 1 Insert the drain hose in the drain pipe as shown in the following figure, so it will **NOT** be pulled out of the drain pipe.




To connect the piping on right side, right-back, or right-bottom

i INFORMATION

The factory default is right-side piping. For left-side piping, remove the piping from the right side and install it on the left side.

- 1 Attach the drain hose with adhesive vinyl tape to the bottom of the refrigerant pipes.
- 2 Wrap the drain hose and the refrigerant pipes together using insulation tape.



- A Right-side piping
- B Right-bottom piping
- C Right-back piping

- a Remove the pipe port cover here for right side piping
- b Remove the pipe port cover here for right-bottom piping

To connect the piping on left side, left-back, or left-bottom

i INFORMATION


The factory default is right-side piping. For left-side piping, remove the piping from the right side and install it on the left side.

- 1 Remove the insulation fixing screw on the right side and remove the drain hose.
- 2 Remove the drain plug on the left side and attach it to the right side.

! NOTICE


Do NOT apply lubricating oil (refrigerant oil) to the drain plug when inserting it. The drain plug may deteriorate and cause drain leakage from the plug.

- 3 Insert the drain hose on the left side and do not forget to tighten it with the fixing screw; otherwise water leakage may occur.



- a Insulation fixing screw
- b Drain hose


- 4 Attach the drain hose to the refrigerant piping bottom side using adhesive vinyl tape.



- A Left-side piping
- B Left-back piping
- C Left-bottom piping
- a Remove the pipe port cover here for left-side piping
- b Remove the pipe port cover here for left-bottom piping

To check for water leaks

- 1 Remove the air filters.
- 2 Gradually pour approximately 1 l of water in the drain pan, and check for water leaks.



6 Piping installation

6.1 Preparing refrigerant piping

6.1.1 Refrigerant piping requirements

! NOTICE

The piping and other pressure-containing parts shall be suitable for refrigerant. Use phosphoric acid deoxidised seamless copper for refrigerant.

- Foreign materials inside pipes (including oils for fabrication) must be ≤ 30 mg/10 m.

Refrigerant piping diameter

Use the same diameters as the connections on the outdoor units:

Class	L1 liquid piping	L1 gas piping
20~42	Ø6.4	Ø9.5

6.1.2 Refrigerant piping insulation

- Use polyethylene foam as insulation material:
 - with a heat transfer rate between 0.041 and 0.052 W/mK (0.035 and 0.045 kcal/mh°C)
 - with a heat resistance of at least 120°C
- Insulation thickness

Pipe outer diameter (Ø _p)	Insulation inner diameter (Ø _i)	Insulation thickness (t)
6.4 mm (1/4")	8~10 mm	≥10 mm



If the temperature is higher than 30°C and the humidity is higher than RH 80%, the thickness of the insulation materials should be at least 20 mm to prevent condensation on the surface of the insulation.

6.2 Connecting the refrigerant piping



DANGER: RISK OF BURNING/SCALDING




WARNING

- Only use R32 as refrigerant. Other substances may cause explosions and accidents.
- R32 contains fluorinated greenhouse gases. Its global warming potential (GWP) value is 675. Do NOT vent these gases into the atmosphere.
- When charging refrigerant, ALWAYS use protective gloves and safety glasses.

6.2.1 Guidelines when connecting the refrigerant piping


Take the following guidelines into account when connecting pipes:

- Coat the flare inner surface with ether oil or ester oil when connecting a flare nut. Tighten 3 or 4 turns by hand, before tightening firmly.



7 Electrical installation

- ALWAYS use 2 wrenches together when loosening a flare nut.
- ALWAYS use a spanner and torque wrench together to tighten the flare nut when connecting the piping. This to prevent nut cracking and leaks.



- a Torque wrench
- b Spanner
- c Piping union
- d Flare nut

Piping size (mm)	Tightening torque (N·m)	Flare dimensions (A) (mm)	Flare shape (mm)
Ø6.4	15~17	8.7~9.1	
Ø9.5	33~39	12.8~13.2	


6.2.2 To connect the refrigerant piping to the indoor unit



WARNING: MILDLY FLAMMABLE MATERIAL

The refrigerant inside this unit is mildly flammable.

- **Pipe length.** Keep refrigerant piping as short as possible.
- Connect refrigerant piping to the unit using **flare connections**.
- Pipework shall be protected from physical damage.
- **Insulate** the refrigerant piping, interconnection cable and drain hose on the indoor unit as follows:



- a Gas pipe
- b Gas pipe insulation
- c Interconnection cable
- d Liquid pipe
- e Liquid pipe insulation
- f Finishing tape
- g Drain hose



NOTICE

Make sure to insulate all refrigerant piping. Any exposed piping might cause condensation.

6.3 Checking the refrigerant piping

6.3.1 To check for leaks



NOTICE

Do NOT exceed the unit's maximum working pressure (see "PS High" on the unit name plate).



NOTICE

ALWAYS use a recommended bubble test solution from your wholesaler.

NEVER use soap water:

- Soap water may cause cracking of components, such as flare nuts or stop valve caps.
- Soap water may contain salt, which absorbs moisture that will freeze when the piping gets cold.
- Soap water contains ammonia which may lead to corrosion of flared joints (between the brass flare nut and the copper flare).

- 1 Charge the system with nitrogen gas up to a gauge pressure of at least 200 kPa (2 bar). It is recommended to pressurize to 3000 kPa (30 bar) in order to detect small leaks.
- 2 Check for leaks by applying the bubble test solution to all connections.
- 3 Discharge all nitrogen gas.

6.3.2 To perform vacuum drying

- 1 Vacuum the system until the pressure on the manifold indicates -0.1 MPa (-1 bar).
- 2 Leave as is for 4-5 minutes and check the pressure:

If the pressure...	Then...
Does not change	There is no moisture in the system. This procedure is finished.
Increases	There is moisture in the system. Go to the next step.

- 3 Vacuum the system for at least 2 hours to a manifold pressure of -0.1 MPa (-1 bar).
- 4 After turning the pump OFF, check the pressure for at least 1 hour.
- 5 If you do NOT reach the target vacuum or CANNOT maintain the vacuum for 1 hour, do the following:
 - Check for leaks again.
 - Perform vacuum drying again.

7 Electrical installation



DANGER: RISK OF ELECTROCUTION



WARNING

ALWAYS use multicore cable for power supply cables.



WARNING

If the supply cord is damaged, it MUST be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



WARNING

Do NOT connect the power supply to the indoor unit. This could result in electrical shock or fire.



WARNING

- Do NOT use locally purchased electrical parts inside the product.
- Do NOT branch the power supply for the drain pump, etc. from the terminal block. This could result in electrical shock or fire.



WARNING

Keep the interconnection wiring away from copper pipes without thermal insulation as such pipes will be very hot.


7.1 Specifications of standard wiring components

Component		
Power supply cable	Voltage	220~240 V
	Phase	1~
	Frequency	50 Hz
	Wire sizes	Must comply with applicable legislation
Interconnection cable		Minimum cable section of 2.5 mm ² and applicable for 220~240 V
Recommended field fuse		20 A
Earth leakage circuit breaker		Must comply with applicable legislation

7.2 To connect the electrical wiring to the indoor unit

Electrical work should be carried out in accordance with the installation manual and the national electrical wiring rules or code of practice.

- 1 Set the indoor unit on the mounting plate hooks. Use the "△" marks as a guide.



- a Mounting plate (accessory)
- b Interconnection cable
- c Wire guide

- 2 Open the front panel, and then the service cover. Refer to "5.2 Opening the indoor unit" ▶ 6].
- 3 Pass the interconnection cable from the outdoor unit through the feed-through wall hole, through the back of the indoor unit and through the front side.

Note: In case the interconnection cable was stripped in advance, cover the ends with insulating tape.

- 4 Bend the end of the cable up.




NOTICE

- Be sure to keep the power line and transmission line apart from each other. Transmission wiring and power supply wiring may cross, but may NOT run parallel.
- In order to avoid any electrical interference the distance between both wirings should ALWAYS be at least 50 mm.




WARNING

Provide adequate measures to prevent that the unit can be used as a shelter by small animals. Small animals that make contact with electrical parts can cause malfunctions, smoke or fire.



- a Terminal block
- b Electrical component block
- c Cable clamp


- 5 Strip the wire ends approximately 15 mm.
- 6 Match wire colours with terminal numbers on the indoor unit terminal blocks and firmly screw the wires to the corresponding terminals.
- 7 Connect the earth wire to the corresponding terminal.
- 8 Firmly fix the wires with the terminal screws.
- 9 Pull the wires to make sure that they are securely attached, then retain the wires with the wire retainer.
- 10 Shape the wires so that the service cover fits securely, then close the service cover.



8 Finishing the indoor unit installation

8.1 To insulate the drain piping, refrigerant piping and interconnection cable

- 1 After the drain piping, refrigerant piping and the electrical wiring are finished. Wrap refrigerant pipes, interconnection cable and drain hose together using insulation tape. Overlap at least half the width of the tape with each turn.




- a Drain hose
- b Interconnection cable
- c Mounting plate (accessory)
- d Refrigerant piping
- e Indoor unit fixing screw M4×12L (accessory)
- f Bottom frame

8.2 To pass the pipes through the wall hole

- 1 Shape the refrigerant pipes along the pipe path marking on the mounting plate.


9 Configuration



- a Drain hose
- b Caulk this hole with putty or caulking material
- c Adhesive vinyl tape
- d Insulation tape
- e Mounting plate (accessory)

NOTICE


- Do NOT bend refrigerant pipes.
- Do NOT push the refrigerant pipes onto the bottom frame or the front grille.



- 2 Pass the drain hose and refrigerant pipes through the wall hole.

8.3 To fix the unit on the mounting plate

- 1 Set the indoor unit on the mounting plate hooks. Use the "△" marks as a guide.



- 2 Press the bottom frame of the unit with both hands to set it on the bottom hooks of the mounting plate. Make sure that the wires do NOT get squeezed anywhere.

Note: Take care that the interconnection cable does NOT get caught in the indoor unit.


- 3 Press the bottom edge of the indoor unit with both hands until it is firmly caught by the mounting plate hooks.
- 4 Secure the indoor unit to the mounting plate using 2 indoor unit fixing screws M4×12L (accessory).

9 Configuration

9.1 To set a different address

In case 2 indoor units are installed in 1 room, different addresses for 2 user interfaces can be set.

- 1 Remove the batteries from the user interface.
- 2 Cut the address jumper.



a Address jumper



NOTICE

Be careful NOT to damage any of the surrounding parts when cutting the address jumper.

- 3 Turn the power supply on.

Result: The flap of the indoor unit will open and close to set the reference position.



INFORMATION

- For FTXF, ATXF, CTXF units, the following setting MUST be completed within 5 minutes after the power supply is turned on.
- In case you could NOT complete the setting in time, turn the power supply off and wait at least 1 minute before turning the power supply back on.

- 4 Press simultaneously:

Model	Buttons
FTXF, CTXF, ATXF	MODE, ↑TEMP and ↓TEMP

- 5 Press:


Model	Button
FTXF, CTXF, ATXF	MODE

- 6 Select:

Model	Symbol
FTXF, CTXF, ATXF	7

- 7 Press:

Model	Button
FTXF, CTXF, ATXF	ON/OFF



- a Operation lamp
- b Indoor unit ON/OFF switch

- 8 Press the indoor unit ON/OFF switch while the operation lamp is blinking.

Jumper	Address
Factory setting	1
After cutting with nippers	2

**INFORMATION**

If the setting could NOT be completed while the operation lamp was blinking, repeat the setting process from the beginning.

9 When the setting is complete, press:

Model	Button
FTXF, CTXF, ATXF	

Result: The user interface will return to the previous screen.

10 Commissioning

**NOTICE**

ALWAYS operate the unit with thermistors and/or pressure sensors/switches. If NOT, burning of the compressor might be the result.

10.1 Checklist before commissioning

After the installation of the unit, first check the items listed below. Once all checks are fulfilled, the unit must be closed. Power-up the unit after it is closed.

☐	You read the complete installation instructions, as described in the installer reference guide .
☐	The indoor units are properly mounted.
☐	The outdoor unit is properly mounted.
☐	Air inlet/outlet Check that the air inlet and outlet of the unit is NOT obstructed by paper sheets, cardboard, or any other material.
☐	There are NO missing phases or reversed phases .
☐	The refrigerant pipes (gas and liquid) are thermally insulated.
☐	Drainage Make sure drainage flows smoothly. Possible consequence: Condensate water might drip.
☐	The system is properly earthed and the earth terminals are tightened.
☐	The fuses or locally installed protection devices are installed according to this document, and have NOT been bypassed.
☐	The power supply voltage matches the voltage on the identification label of the unit.
☐	The specified wires are used for the interconnection cable .
☐	The indoor unit receives the signals of the user interface .
☐	There are NO loose connections or damaged electrical components in the switch box.
☐	The insulation resistance of the compressor is OK.
☐	There are NO damaged components or squeezed pipes on the inside of the indoor and outdoor units.
☐	There are NO refrigerant leaks .
☐	The correct pipe size is installed and the pipes are properly insulated.



The **stop valves** (gas and liquid) on the outdoor unit are fully open.

10.2 To perform a test run

Prerequisite: Power supply MUST be in the specified range.

Prerequisite: Test run may be performed in cooling or heating mode.

Prerequisite: Test run should be performed in accordance with the operation manual of the indoor unit to make sure that all functions and parts are working properly.

- 1 In cooling mode, select the lowest programmable temperature. In heating mode, select the highest programmable temperature. Test run can be disabled if necessary.
- 2 When the test run is finished, set the temperature to a normal level. In cooling mode: 26~28°C, in heating mode: 20~24°C.
- 3 The system stops operating 3 minutes after the unit is turned OFF.

10.2.1 To perform a test run in winter season

When operating the air conditioner in **Cooling** mode in winter, set it to test run operation using the following method.

**INFORMATION**

Some of the functions CANNOT be used in the test run operation mode.

If a power failure occurs during operation, the system automatically restarts immediately after power is restored.

For FTXF, ATXF, CTXF units

- 1 Press to switch the system on.
- 2 Press the centre of , , and simultaneously.
- 3 Press twice.

Result: will appear on the display. Test run operation is selected. Test run operation will stop automatically after about 30 minutes.

- 4 To stop operation, press .

11 Disposal

**NOTICE**

Do NOT try to dismantle the system yourself: dismantling of the system, treatment of the refrigerant, oil and other parts MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.


12 Technical data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin Business Portal (authentication required).

12.1 Wiring diagram

12.1.1 Unified wiring diagram legend

For applied parts and numbering, refer to the wiring diagram on the unit. Part numbering is by Arabic numbers in ascending order for each part and is represented in the overview below by "*" in the part code.

Symbol	Meaning	Symbol	Meaning
	Circuit breaker		Protective earth
	Connection		Protective earth (screw)
	Connector		Rectifier
	Earth		Relay connector
	Field wiring		Short-circuit connector
	Fuse		Terminal
	Indoor unit		Terminal strip
	Outdoor unit		Wire clamp
	Residual current device		

Symbol	Colour	Symbol	Colour
BLK	Black	ORG	Orange
BLU	Blue	PNK	Pink
BRN	Brown	PRP, PPL	Purple
GRN	Green	RED	Red
GRY	Grey	WHT	White
		YLW	Yellow

Symbol	Meaning
A*P	Printed circuit board
BS*	Pushbutton ON/OFF, operation switch
BZ, H*O	Buzzer
C*	Capacitor
AC*, CN*, E*, HA*, HE*, HL*, HN*, HR*, MR*_A, MR*_B, S*, U, V, W, X*A, K*R_*, NE	Connection, connector
D*, V*D	Diode
DB*	Diode bridge
DS*	DIP switch
E*H	Heater
FU*, F*U, (for characteristics, refer to PCB inside your unit)	Fuse
FG*	Connector (frame ground)
H*	Harness
H*P, LED*, V*L	Pilot lamp, light emitting diode

Symbol	Meaning
HAP	Light emitting diode (service monitor green)
HIGH VOLTAGE	High voltage
IES	Intelligent eye sensor
IPM*	Intelligent power module
K*R, KCR, KFR, KHuR, K*M	Magnetic relay
L	Live
L*	Coil
L*R	Reactor
M*	Stepper motor
M*C	Compressor motor
M*F	Fan motor
M*P	Drain pump motor
M*S	Swing motor
MR*, MRCW*, MRM*, MRN*	Magnetic relay
N	Neutral
n=*, N=*	Number of passes through ferrite core
PAM	Pulse-amplitude modulation
PCB*	Printed circuit board
PM*	Power module
PS	Switching power supply
PTC*	PTC thermistor
Q*	Insulated gate bipolar transistor (IGBT)
Q*C	Circuit breaker
Q*DI, KLM	Earth leak circuit breaker
Q*L	Overload protector
Q*M	Thermo switch
Q*R	Residual current device
R*	Resistor
R*T	Thermistor
RC	Receiver
S*C	Limit switch
S*L	Float switch
S*NG	Refrigerant leak detector
S*NPH	Pressure sensor (high)
S*NPL	Pressure sensor (low)
S*PH, HPS*	Pressure switch (high)
S*PL	Pressure switch (low)
S*T	Thermostat
S*RH	Humidity sensor
S*W, SW*	Operation switch
SA*, F1S	Surge arrester
SR*, WLU	Signal receiver
SS*	Selector switch
SHEET METAL	Terminal strip fixed plate
T*R	Transformer
TC, TRC	Transmitter
V*, R*V	Varistor
V*R	Diode bridge, Insulated-gate bipolar transistor (IGBT) power module
WRC	Wireless remote controller
X*	Terminal

Symbol	Meaning
X*M	Terminal strip (block)
Y*E	Electronic expansion valve coil
Y*R, Y*S	Reversing solenoid valve coil
Z*C	Ferrite core
ZF, Z*F	Noise filter

**DAIKIN ISITMA VE SOĞUTMA SİSTEMLERİ SAN.TİC. A.Ş.**

Gülsuyu Mahallesi, Fevzi Çakmak Caddesi, Burçak Sokak, No:20, 34848 Maltepe

İSTANBUL / TÜRKİYE

Tel: 0216 453 27 00

Faks: 0216 671 06 00

Çağrı Merkezi: 444 999 0

Web: www.daikin.com.tr

Copyright 2020 Daikin

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

3P519299-11X 2020.12