



#### NOTES

- Electric box can also be fixed on the other side of the unit.
- Be sure to install an inspection door at electric box side.
- Attached pipe(1) and Attached pipe(2) is used in case of connecting with indoor capacity index more than 160 and less than 200. In case of connecting one indoor unit of 200 type, only gas pipe connection port need Attached pipe(1).
- Small sound will be made when changing over the motor operated valve, which may be disturbing.  
Do not install it at the place such as bedroom under roof.

Nr.	Part name	Description
10	Attached pipe(2) (Note. 3)	ø 15.9mm brazing connection
9	Attached pipe(1) (Note. 3)	ø 19.1mm brazing connection
8	Grounding terminal	M4
7	Suspension brackets	M8-M10
6	Electric box (Note 1.)	
5	Liquid pipe connection port	ø 9.5mm brazing connection
4	Gas pipe connection port	ø 22.2mm brazing connection
3	Liquid pipe connection port	ø 9.5mm brazing connection
2	HP/LP gas pipe connection port	ø 19.1mm brazing connection
1	Suction gas pipe connection port	ø 22.2mm brazing connection