

EUWAB5-8KBZW1

- 1 Air heat exchanger
 - 2 Compressor
 - 3 Switch box
 - 4 Main switch
 - 5 Pump switch
 - 6 Digital display controller
 - 7 Water heat exchanger
 - 8 Water IN connection: 1 1/4" M BSP
 - 9 Water OUT connection: 1 1/4" M BSP
 - 10 Power supply intake
 - 11 Drain
 - 12 Air purge
 - 13 Expansion vessel
 - 14 Safety valve
 - 15 Manometer (water)
 - 16 Pressure port
 - 17 Ball valve: 1-1/4" BSP
 - 18 Water filter: 1-1/4" BSP
 - 19 Pump
 - 20 Regulation valve
 - 21 Flow switch
 - 22 High pressure gauge (optional)
 - 23 Low pressure gauge (optional)
 - 24 Pump drain
 - 25 Buffer tank
 - 26 4 way valve *
 - 27 Accumulator *
 - 28 Liquid receiver *
- * Only for H/P models

