



Manufacturer label




Product liability label

In case of removing the stop valve cover.



Outdoor air temperature thermistor



## Minimum space for air passage

Wall height on air outlet side < 1200 mm

