


RKHBRD-ADV17


Detail A
Scale 1/3

If required (e.g. Wall fixation)
Pressure gauge can be removed from
waterfilter, maximum distance between
waterfilter and pressure gauge +/- 600mm



left installation

right installation



- 1 Gas pipe connection ϕ 15.9 Solder (R410A)
- 2 Liquid pipe connection ϕ 9.5 Solder (R410A)
- 3 R134a Service ports ϕ 12.7 flare
- 4 Pressure gauge
- 5 Blow off valve
- 6 Drain valve water circuit
- 7 Air purge
- 8 Shut-off valves
- 9 Water filter
- 10 Water in connection G 1" (Female)
- 11 Water out connection G 1" (Female)
- 12 Control wiring intake (Knock-out hole ϕ 37)
- 13 Power supply wiring intake (Knockout hole ϕ 37)
- 14 Knock-out holes for refrigerant piping and water piping
- 15 Levelling feet
- 16 Remote controller (delivered as accessory)
Installation location is outside the unit

