







UATYA80-120BFC3Y1



Air direction			
Air direction	Discharge	Intake	External
Left	LD	/	LE
Right	RD	RI	/
Bottom	BD	/	/
Front	FD	/	/


Sci | Signal cables inlet

Ead | External air damper

Esi | Electrical supply inlet

Cd | Condensate drain 1" male

Rfi | Remove for inspection

 | Clearances