



FHA-A(9)


Remote control dimensions



Receiver installation procedure



Installation to wall surface



Receiver detail

