




Remote control dimensions




Receiver installation procedure



Remote controller holder installation procedure (installation to wall surface)



Receiver detail



Wireless remote control kit for each decoration panel

Wireless remote control kit	Decoration panel
BRC7F532F BRC7F533F	BYCQ140CW1