





The mark (→) shows piping direction



Model name Plate

FLAP AND LOUVER ANGLE


Up/Down (Flap, Automatic)
Cool, dry and fan



Right/Left (Louver, Manual)




Signal transmitter




INFRARED REMOTE CONTROL
ARC461A1

(Including mounting plate)




Name Plate

Terminal block and Earth Terminal (Inside)



REQUIRED SPACE




Gas pipe $\varnothing$ 12.7 CuT
(The length of pipe outside the unit: about 350mm)

Liquid pipe $\varnothing$ 6.4 CuT
(The length of pipe outside the unit: about 400mm)

Drain hose
(Connecting part I.D $\varnothing$ 14 O.D. $\varnothing$ 16)

The hose length of outside the unit is approx. 450mm



STANDARD LOCATIONS OF WALL HOLES